## METHOD #5 PARALLEL (3P) HIGH LOW SYSTEM

NOTE: FOR BI-METAL VALVES ONLY INCLUDING TYPE TM SERIES



SEE INSTALLATION INSTRUCTIONS FOR VALVE SPECIFIC PIPING DIAGRAMS AND SET UP PROCEDURE.

FOR MULTIPLE TEMPERED LOOPS A BALANCING VALVE AND CHECK VALVE MUST BE INSTALLED ON EACH LOOP AFTER TEMPERED FIXTURES.

© 2015 Leonard Valve Company

Printed in USA

